ITEM NO. :B5226DU-J-20N-C

ASSEMBLY INSTRUCTIONS

1.Drill holes on the wall according to the size of plastic drywall anchor and gently tap the plastic drywall anchor (A) into the hole.

2.Screw the hook (B) into the plastic drywall anchor.

3.Wrap the wires around the hook on the 8-shaped fastener (C) and hang the 8-shaped fastener (C) to the hook (B). You can also hang the wires directly on the hook (B) and manage the wires with the wire wrap strap (D) included.

4.Screw the bulb (E) into the lamp holder.

5.Screw the lampshade (F) into the lamp body.

Please consult a qualified Electrician if you are not familiar with electrical wiring.

