

Model No: B5400DU-BK-C

ASSEMBLY INSTRUCTIONS

1. Drill holes on the wall according to the size of plastic drywall anchor and gently tap the plastic drywall anchor (A) into the hole.
2. Screw the hook (B) into the plastic drywall anchor.
3. Hang the chain (C) onto the hook (B).
4. Wrap the wires around the figure-8 fastener (D) and hang it onto the hook (B).
5. Attach the lampshade (F) to the lamp holder (E) using the socket ring (G) to secure.
6. Screw the bulb (H) into the lamp holder.

Please consult a qualified Electrician if you are not familiar with electrical wiring.

