

ASSEMBLY INSTRUCTIONS

2. Connect the fixture wire to the circuit wire with the wire nuts (C): black wire with live wire, white wire with neutral wire, ground wire with ground wire. Turn the wire nuts to twist the wires together. Wrap the wire nuts with insulated rubber tape.

4.Screw the acrylic lampshade (F) into the aluminium cover on the lamp body (G).

Please consult a qualified Electrician if you are not familiar with electrical wiring.

