

Model No: W1010ZU

ASSEMBLY INSTRUCTIONS

1. Mark the mounting holes on the wall according to the hole spacing of the fixture base and drill holes on the wall (A).
2. Gently tap the plastic drywall anchors (B) into the hole with a hammer.
3. Connect the fixture wire to the circuit wire with the wire nuts (C): black wire with live wire, white wire with neutral wire, ground wire with ground wire. Turn the wire nuts to twist the wires together. Wrap the wire nuts with insulated rubber tape.
4. Attach the base (D) of the lamp body to the wall using the screws (E) to secure.
5. Screw the bulb (F) into the lamp holder.
6. Attach the top cover (G) to the screw on the lampshade using the nut (H) to secure.

Please consult a qualified Electrician if you are not familiar with electrical wiring.

