

Model No: T3358BU-C

ASSEMBLY INSTRUCTIONS

1. Fix the lamp body (A) to the canopy (B) and secure with the nuts (C).
2. Mark the mounting holes on the wall according to the hole spacing of a mounting plate and drill holes on the wall (D).
3. Gently tap the plastic drywall anchors (E) into the hole with a hammer.
4. Install the mounting plate (F) on the wall with the screws (G).
5. Fix the canopy (B) to the mounting plate (F) with the screws (H).
6. Place the lamp shade (J) on the socket and secure with the socket ring (K).
7. Screw the bulb (L) into the lamp holder.

Please consult a qualified Electrician if you are not familiar with electrical wiring.

