

Model No: T5396-3DU-BK

ASSEMBLY INSTRUCTIONS

1. Pass the wires through the hanging rods (B) and screw the hanging rods (B) into the threaded tube on the lamp body (A). Connect the hanging rods to the canopy (D) with the carabiner (C).
2. Install the mounting plate (E) on the outlet box with the screws (F).
3. Loosen the hex nuts around the bolts (G) and screw in or unscrew the bolts from the junction box to get the right length for installation.
4. Connect the fixture wire to the circuit wire with the wire nuts (H): live wire (L) (parameters printed on wire cover) with live wire, neutral wire (N) (nothing printed on wire cover) with neutral wire, ground wire with ground wire. Turn the wire nuts to twist the wires together. Wrap the wire nuts with insulated rubber tape.
5. Fix the canopy (D) to the mounting plate (E) with the ball nuts (J).
6. Screw the bulb (K) into the lamp holder.

Please consult a qualified Electrician if you are not familiar with electrical wiring.

