

Model No: T5214DU-C

ASSEMBLY INSTRUCTIONS

1. Drill holes on the wall according to the size of plastic drywall anchor (A) and gently tap the plastic drywall anchor (A) into the hole.
2. Attach the pulley (B) to the wall using the screws (C) to secure.
3. Attach the wire buckle (D) to the wall using the screws (E) to secure and use the side screw (F) to secure the power cord.
4. Place the lamp shade (G) on the socket and tighten it with the socket ring (H).
5. Screw the bulb (J) into the lamp holder.

Please consult a qualified Electrician if you are not familiar with electrical wiring.

