ITEM NO.: B7270-6CU

ASSEMBLY INSTRUCTIONS

- 1. Attach the lamp body (A) to the canopy (B) using the nut (C) to secure.
- 2.Install the mounting plate (D) on the outlet box with the screws (E).
- 3.Loosen the hex nuts around the bolts (F) and screw in or unscrew the bolts from the junction box to get the right length for installation.
- 4. Connect the fixture wire to the circuit wire by wire nuts (G), black wire with live wire, white wire with neutral wire, ground wire with ground wire.
- 5. Attach the canopy (B) to the mounting plate (D) using the ball nuts (H) to secure.
- 6. Screw the bulb (J) into the lamp holder.
- 7. Screw the lampshade (K) into the bobeche gently.

Please consult a qualified Electrician if you are not familiar with electrical wiring.

