

ITEM NO. :B3196BU-C

Installation Process Without a Junction Box

ASSEMBLY INSTRUCTIONS

1. Fix the lamp body (A) to the canopy (B) and secure with the nuts (C).
2. Mark the mounting holes on the wall according to the hole spacing of a mounting plate and drill holes on the wall (D).
3. Gently tap the plastic drywall anchors (E) into the hole with a hammer.
4. Attach the the mounting plate (F) to the wall and secure it with self-tapping screws (G).
5. Pass the power cords (H) through the hole on the canopy, adjust the length of cords, and fasten the cords with an 8-shaped fastener.
6. Twist the wires of the power cords together and connect the power cords (J) with the terminal: connect the dimmer's long wire to the live wire (L) of the power cord, connect the dimmer's short wire to the black fixture wire, and connect the fixture's white wire to the neutral wire (N) of the power cord.
7. Wrap a few loops of the ground wire (K) around the green screw on the mounting plate (F) and then tighten the green screw.
8. Attach the lamp body (B) to the mounting plate (F) using the ball nuts (L) to secure.
9. Place the lamp shade (M) on the socket and secure with the socket ring (N).

Please consult a qualified Electrician if you are not familiar with electrical wiring.

