

ITEM NO. :B5135DU-C

ASSEMBLY INSTRUCTIONS

1. Drill holes on the wall according to the size of plastic drywall anchor and gently tap the plastic drywall anchor (A) into the hole.
2. Screw the hook (B) into the plastic drywall anchor.
3. Wrap the wire around the hook and manage the excess wire with wire wrap straps (C) (or in other ways you like).
4. Screw the bulb (D) into the lamp holder.
5. Screw the lampshade (E) into the lamp body.

Please consult a qualified Electrician if you are not familiar with electrical wiring.

