


Model No: B3084BU-J-C

Installation with Junction Box-Hardwired


ASSEMBLY INSTRUCTIONS

1. Drive the screws (C) into the screw holes 70MM apart on the mounting plate (A) and separate the wires inside the canopy one by one.
2. Install the mounting plate (A) on the outlet box with the screws (B).
3. Screw in or unscrew the bolts (C) from the junction box to get the right length for installation, and tighten the bolts (C) with the hex nuts.
4. Connect the fixture wire to the circuit wire with the wire nuts (D): black wire with live wire, white wire with neutral wire, ground wire with ground wire. Turn the wire nuts to twist the wires together. Wrap the wire nuts with insulated rubber tape.
5. Fix the canopy (E) to the mounting plate (A) with the ball nuts (F).
6. Screw the bulb (G) into the lamp holder.
7. Screw the lampshade (H) into the lamp holder gently.

Please consult a qualified Electrician if you are not familiar with electrical wiring.



Recommended bulb shape



Used for Junction Box

