ITEM NO.: B7106CU

ASSEMBLY INSTRUCTIONS

- 1. Attach the socket rod (A) to the canopy (C) and secure the rods with the nut (D).
- 2.Attach the connecting rods (B) to the canopy (C) and secure the rods with the nut (D).
- 3.Put the metal rings (E) around the connecting rods (B) and secure the rings with the nuts (F).
- 4. Screw the bulb (G) into the lamp holder.
- 5. Screw the lampshade (H) into the bobeche gently.
- 6. Adjust the length of the screw (K) to suit your needs.
- 7.Install the mounting plate (J) on the outlet box with the screws (L).
- 8. Connect the fixture wire to the mains wire with the wire nuts (M), black wire with live wire, white wire with negative wire, ground wire with ground wire.
- 9. Fix the lamp body (C) to the mounting plate (J) with the ball nuts (N).

Please consult a qualified Electrician if you are not familiar with electrical wiring.

