ITEM NO. : B7107-3CU

ASSEMBLY INSTRUCTIONS

1.Attach the socket rod (A) to the canopy (B) and secure the rods with the nut (C)

3.Install the mounting plate (E) on the outlet box with the screws (F) 2.Loosen the hex nut around the bolt (D) and screw in or unscrew the bolt from the junction box to get the right length for installation.

4.Connect the fixture wire to the mains wire with the wire nuts (G), black wire with live wire,

white wire with negative wire, ground wire with ground wire.

5. Fix the lamp body (B) to the mounting plate (E) with the ball nuts (H).

6.Screw the bulb (J) into the lamp holder.

7.Screw the lampshade (K) into the bobeche gently.

Please consult a qualified Electrician if you are not familiar with electrical wiring.

