TEM NO.:T5218-9DU

14.Loosen the hex nuts around the bolts (14) and screw in or unscrew the bolts

with live wire, white wire with neutral wire, ground wire with ground wire.

