

ITEM NO. :T3345BU-BK-C

Installation Process Without a Junction Box

ASSEMBLY INSTRUCTIONS

- 1.Mark the mounting holes on the wall according to the hole spacing of a mounting plate and drill holes on the wall (A).
- 2.Gently tap the plastic drywall anchors (B) into the hole with a hammer.
- 3.Install the mounting plate (C) on the outlet box with the screws (D).
- 4.Wrap a few loops of the ground wire (E) around the green screw on the mounting plate (C) and then tighten the green screw.
- 5.Fix the canopy (F) to the mounting plate (C) with the ball nuts (G).
- 6.Screw the bulb (H) into the lamp holder.

Please consult a qualified Electrician if you are not familiar with electrical wiring.

