ITEM NO.: T3291BU

ASSEMBLY INSTRUCTIONS

- 1.Attach the aluminium rods (A) to the canopy using the screws to secure.
- 2.Install the mounting plate (B) on the outlet box with the screws (C).
- 3. Connect the fixture wire to the circuit wire by wire nuts (D), black wire with live wire, white wire with neutral wire, ground wire with ground wire.
- 4. Fix the lamp body (E) to the mounting plate (B) with the ball nuts (F).

Please consult a qualified Electrician if you are not familiar with electrical wiring.



