

ASSEMBLY INSTRUCTIONS

1. Mark the mounting holes on the wall according to the hole spacing of a mounting plate and drill holes on the wall (A).
2. Gently tap the plastic drywall anchors (B) into the hole with a hammer.
3. Attach the mounting plate (C) to the wall with self-tapping screws (D). Before tightening the self-tapping screws, wrap a few loops of the copper ground wire (E) around one of the screws (D), and tighten the screws to attach the ground wire to the mounting plate.
4. Fix the canopy (F) to the mounting plate (C) with the screws (G).
5. Screw the rod (H) into the lamp body (J).
6. Place the lamp shade (K) on the socket and tighten it with the socket ring (L).
7. Screw the bulb (M) into the lamp holder.

Please consult a qualified Electrician if you are not familiar with electrical wiring.

