

ITEM NO. :T7272-4CU

ASSEMBLY INSTRUCTIONS

- 1.Pass the wires through the connecting rod in the middle (A) and screw the connecting rod into the joint nut on the break (B).
- 2.Attach the connecting rods (C) to the lower rectangular frame (D) using the screws (E) to secure.
- 3.Attach the arched flat iron bars (F) and the upper rectangular frame (G) to the connecting rods (C) using the screws (H) to secure.
- 4.Put the lamp body (J) inside the assembled rectangular frame (K) and tighten the joint nut on the canopy (L) to secure.

Please consult a qualified Electrician if you are not familiar with electrical wiring.

