

ITEM NO. :T7295CU

ASSEMBLY INSTRUCTIONS

- 1.Install the mounting plate (A) on the outlet box by using the screws (B).
- 2.Connect the fixture wire to the circuit wire by wire nuts (C), black wire with live wire, white wire with neutral wire, ground wire with ground wire.
- 3.Fix the lamp body (D) to the mounting plate (A) by the ball nuts (E).
- 4.Screw the connecting rod (F) into the joint connector nut on the lamp body (D). Adjust the length of the connecting rod to the perfect length for securing the glass shade and secure the connecting rod with the nut on the rod.
- 5.Adjust the position of the nut (G) and the spacers. (Make sure the bottom of the glass sheet aligns with the bottom of the lampshade.)
- 6.Put the glass sheet (H) , the silicone spacer (J), and the iron spacer (K) around the connecting rod (F) one by one and secure the glass sheet with the nut (L).

Please consult a qualified Electrician if you are not familiar with electrical wiring.

